

MARINE SERVICE CONTRACT

BOAT WITH CONFIDENCE!

Your Service Contract Protects Your Budget From Unexpected Repair and Replacement Costs Like These!*



Let's face it... boat ownership comes with a lot of unexpected expenses. With a Marine Vehicle Service contract, we cover the costs associated with repairing or replacing covered components that fails during the term of your contract.

We offer multiple levels of coverage, flexible terms, and several accessory packages to choose from, so you can boat with confidence for years to come!

PROTECT YOUR BOAT FROM THESE UNEXPECTED REPAIR AND REPLACEMENT COSTS!

Engine Components	AVG Cost*
Fuel Delivery System	\$1,900
Lower Unit	\$1,600
Jet Drive	\$1,100
Ignition	\$750
Power Trim and/or Tilt	\$2,400
Transmission	\$3,300
V-Drive	\$3,400
Stern Drive Upper Housing	\$2,700
Stern Drive Lower Unit	\$4,100

Accessory Components	AVG Cost*
Factory-Installed Depth Finder	\$1,200
Electrical & Heating	\$900
Planing System	\$2,800
Ski / Wakeboard Tower	\$7,500
Electric / Gas Trolling Motor	\$1,500
Axillary Generator	\$4,300
Bow Thrusters	\$1,600
Electronic Components	\$4,200
Inboard Drive Line	\$4,400



The prices listed in this presentation are sample costs based on historical data and are for illustrative purposes only. Actual costs vary according to year, make, and model, and from state to state. Please ask to see a sample contract for coverage details.

MARINE SERVICE CONTRACT ACCESSORY PACKAGES

COVERAGE DETAILS

[BACK TO FIRST PAGE](#)

The prices listed in this presentation are sample costs based on historical data and are for illustrative purposes only. Actual costs vary according to year, make, and model, and from state to state. Please ask to see a sample contract for coverage details.

OFFSHORE SPORT FISHING PACKAGE

Electric Trolling Motor (One motor only as originally equipped): Armature, fields, brushes, brush holders, wiring harness, control cables, foot control unit and switches. Planetary/armature housing if damaged beyond repair by one of the above parts.

Gas Trolling Motor (One motor only up to 15 HP as originally equipped): All internally lubricated parts contained within the engine block, fuel pump, carburetor, wiring harness, control cables, foot control unit and switches.

Manual/Hydraulic Steering: Tiller arm, drag link, stabilizer, rudder shaft tiller arm, U-joints, torque tube, gear box, steering control helm assembly, control rack and yoke assembly, steering wheel, steering wheel mounting hub, shift and throttle control box parts including: cams, eccentrics, shafts, pivots, bushings, housing, control arms/levers and knobs, shift control cable, throttle control cable and control valve; steering control helm assembly, control rack and yoke assembly, power steering pump, power steering cylinder, steering wheel and hub, hydraulic steering head, hydraulic steering lines, hydraulic steering cylinder, hydraulic steering flow valves.

Electrical: Battery main switch, battery isolator, battery selector switch, battery box, battery charger, fuse block, fuse holders, chart light, engine hatch motor, engine hatch switch, windshield wiper motor, transom light, volt meter, courtesy lights, air compressor.

Electronics (Factory installed only): Cruise control, GPS system, TV, DVD player, CD player, CD changer, amplifier, cassette tape deck, AM/FM/Satellite tuner, digital music player dock, wireless communication system, CO detectors, LP detectors.

Air Conditioning (Factory installed only): Compressor, condenser, capacitor, water pump, relay, fans, heat exchanger, evaporator, control panel, thermostat.

Power Top: Switches, solenoids, motor, wiring, frame and track.

Bilge Blower: Control panel switch, wiring harness, blower motor.

Instrument Panel (Factory installed only): Gauges and sensors; video display monitor; instrument groupings.

Water System/Washdown: Water pumps, water heater, shower drain sump pump, drain system, fittings, faucets.

Waste System: Shower, toilet, sink(s), holding tanks, macerator, gate valves, connections, electric flush control, vacuum pump.

Lighting (Fixture & switches only): Interior light switches, navigation lights, anchor lights, docking lights, bow light, docking lights.

Appliances (Built-in): Refrigerator, range/cook top, oven, L.P. regulator, microwave, ice-maker.

Shore Power: Onboard receptacle, cap, shore power main switch, circuit panel, circuit breakers.

Remote Spotlight: Control panel, horizontal/vertical control motors, light housing.

Horns: Air horns, air horn compressor, air solenoids, control panel, electric horn and control.

Live Wells: Fill/main pumps, aerator, manual valves, timer.

Power Transom/Jack Plate: Motor bracket, slides, jack screws, cylinder, control panel.

Planing/Trim Tabs: Pump/motor, trim cylinders, planing plates.

Anchor: Winch, electric windlass motor, bow pulpit guide, control panel.

Depth Finder (Factory installed only): Head unit, Depth sounder, transducer, mounting brackets, control cable, wiring harness.

Fish Finder (Factory installed only): Fish finder, transducer, speed and temperature sensors, mounting brackets, control cable.

Battery Charger (Factory installed only)

Lake water Temperature Gauge (Hull mounted only): Temperature gauge, temp sensor and control cable.

Compass: Compass head, mounting brackets.

Stern Thrusters/Bow Thruster: Electric motor, wiring harness, control panel, bow thruster battery charger.

Hardware: Deck rails, grab rails, hand rails, bow eyes, rope cleats, anchor chocks, cockpit steps, top slides, door hinges and latches, deck plates, storage cover sockets and supports.

Trailer: Brakes, brake drums, master cylinder and hydraulic brake actuator, frame rails, wheel bearings, spindles and springs, winch stand, welds, axle, backing plates, coupler, bunk and roller cradles. (Excludes damage due to overloading and bending or bearing failures due to water entry or debris.)

GLOBAL